

BMM Explorer Version 3.0

What's New


Improvements

SIMPLIFIED USER INTERFACE AND DATA HANDLING

- ▶ More blast data categories in file navigator
 - ▶ More levels to accommodate mine, pit, phase, bench
 - ▶ Bench mode, with default flitch configurations
 - ▶ Flitch customisation in blast mode
- ▶ User-friendly GUI when importing holes, pre BMMs and post survey data
 - ▶ Integrated filter templates for holes, pre- and post-BMMs, and ore blocks-pre
- ▶ Improved 3D view of blast map


PERFORMANCE AND RELIABILITY

- ▶ Faster importing for large blasts
- ▶ Improved database structure



Free-form tree, easily customized to your specific naming conventions

Spend less time importing blast holes, pre-blast BMMs and post-blast survey data



Blast Movement Technologies

Head Office
2 / 67 Bluestone Circuit
Seventeen Mile Rocks
Queensland, 4073
AUSTRALIA

Africa
Accra
GHANA

www.bmt.com.au

North America
Denver, Colorado
USA

office@bmt.com.au

South America Agent
Lima
PERU